

SONY eReaders Touch Frequently Asked Questions



What is the SONY eReader Touch?



SONY eReader Touch is an electronic book and audio book device that allows users to read books and listen to audio content.

Where can I go to download books to the eReader?



You can download books using various free online book databases including Google Books, www.google.com/books


Can I use my own memory card on it with purchased books?



Yes, you may bring your own memory card (Memory Stick or Memory Stick PRO) with your own content and use the *eReader* to access it.

What are some of the features in this version of the SONY eReader?

- Download capacity up to 350 books
- Touchscreen display lets you turn pages with the swipe of a finger
- Stylus offers freehand highlighting and annotation



ePUB is the preferred downloading format. It provides an interactive Table of Contents - and is easier to browse. Both forms are compatible with SONY eReaders.

Can I download books from the Ebrary database?

Unfortunately, *Ebrary* only permits you to browse eBooks on a computer connected to the Internet. It does not support downloadable content.



